HEBERT GROUP

INSTRUCTIONS FOR DRIVERS

I AM HERE TO UNLOAD

Unloading hours
Monday - Thursday: 08:00-12:00 / 13:30-16:00
Friday: 08:00-12:00

Destinations
Zone 3 | Zone 4 | Zone 6

1 ARRIVAL | INTERCOM ON RUE JEAN HÉBERT

Ring the intercom and enter only once you have been authorised to do so.

2 LOCATION | UNLOADING AREA

Go to the area indicated by the receptionist (zone 3, 4 or 6).

3 RECEPTION | ASSISTANCE

Zones 3 and 4: Wait in your truck. The goods receiving department has been notified; a warehouse operator will assist you.
Zone 6: Report to the goods receiving office.

4 DEPARTURE | EXIT

Zone 3: Exit through the automatic barrier on the opposite side, towards chemin de la Barbuise.
Zone 4: Use the exit on the left, towards chemin de la Barbuise.
Zone 6: Use the second gate to exit towards rue de l'Épinette.

LEAK OR SPILL

If plastic pellets or chemicals (oil, grease) leak or spill, immediately notify a Hébert Group supervisor and use the equipment provided: shovel, hand brush, waste bin and spill kit.

PROHIBITED THROUGHOUT THE SITE

- Littering
- Entering production or finishing areas
- Glass objects
- Snap-off blade knives, drawing pins, staples
- Illegal substances
- Entering buildings unaccompanied
- Touching products